

4-LED LIGHTHEAD 12-24 VDC

WIRING

RED: To +VDC (fuse @ 3A)

BLACK: To Chassis Ground

WHITE: For steady burn, apply +VDC

YELLOW: For Synchronization:
Connect YELLOW wires of all heads together for synchronization
(all heads must be set at the same pattern)

For Simultaneous or Alternating Flash:

1. Apply +VDC to RED and YELLOW wires simultaneously to enter

Grouping; lighthouse will display short (single or double) flashes:

- Single flash = Group1
- Double flash = Group2

2. Momentarily apply +VDC to YELLOW wire to change Groups:

- Heads in the same Group flash together.
- Group1 Heads alternate with Group2 Heads.


For Flash Patterns:

Momentarily apply +VDC to YELLOW wire:

- once for next pattern
- quickly three times for pattern (

FLASH PATTERN

0	Random	10	Double (all)
1	Single (split)	11	Quad (all)
2	Double (split)	12	Quint (all)
3	Quad (split)	13	Mega (all)
4	Quint (split)	14	Ultra (all)
5	Mega (split)	15	Single-Quad (all)
6	Ultra (split)	16	Single H/L (all)
7	Single-Quad (split)	17	Steady (ca)
8	Single H/L (split)	18	Steady 4 (all)
9	Single (all)		



Note: This unit is not factory set at pattern 0